



Instructions

The HoneyBee from CaberLight


UNPACKING:

Remove (and save) the *HoneyBee Cocoon* sleeve (a small cotton sock) which protects the *Light Head* (A.) Grasp your *HoneyBee* clamp and uncurl it as shown (B.)




SETTING UP:

Open the *Clamp* jaws far enough to clamp to the display table by pressing on the release button (C) and sliding the lower jaw down (Red Arrow.)





Hook the clamp over the back edge of the table, and repeatedly squeeze the black & yellow handles together until the unit is solidly clamped to the table.



POWERING UP:

Your *HoneyBee* can be powered by either a *LadyBug Single Power Supply (K)* or a *LadyBug 6-Pack Power Supply (L.)* A *LadyBug Battery Adapter (M,)* plus your 12v battery can power a single *LadyBug* directly, or up to 6 through the wiring harness of a *LadyBug 6-Pack Power Supply (N.)*



Plug in your *HoneyBee*, turn it on, and aim it on your treasures!



PACKING UP:

Turn off and unplug the *HoneyBee* . Unclamp it from the display table by pressing the release button (Arrow) which slides the lower jaw down.



Rotate the *Light Head* so it is parallel with the clamp. Grasp the *HoneyBee Clamp* with one hand and the *Gooseneck* near the *Light Head* with the other, and curl it up until the *Light Head* is over the clamp. Replace the *HoneyBee Cocoon* over the *Lighthhead*, and pack it in the box or your luggage with your power (Q,R) and go home!

